



HP2-T26^{Q&As}

Servicing HP BladeSystem Solutions

Pass HP HP2-T26 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.passapply.com/hp2-t26.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by HP Official Exam Center

- ⚙️ **Instant Download** After Purchase
- ⚙️ **100% Money Back** Guarantee
- ⚙️ **365 Days** Free Update
- ⚙️ **800,000+** Satisfied Customers





QUESTION 1

Which mezzanine card is compatible with the HP ProCurve 6120XG interconnect?

- A. HP NC326m PCIe Dual-Port 1Gb Server Adapter
- B. Emulex LPe1105-HP 4Gb Fibre Channel HBA
- C. HP 4X QDR IB CX-2 Dual Port Mezz HCA for HP BladeSystem c-Class
- D. HP StorageWorks 80GB IO Accelerator for BladeSystem c-Class

Correct Answer: A

QUESTION 2

An HP VC Flex-10 module must be replaced in a c3000 BladeSystem enclosure because one uplink port is defective.

What must be done before physically replacing the module?

- A. Back up the enclosure EBIPA information.
- B. Copy the server profiles to a flash drive.
- C. Copy the VCM logs to a flash drive.
- D. Back up the Virtual Connect settings.

Correct Answer: D

QUESTION 3

Which services and benefits do HP CarePack Services provide? (Select three.)

- A. dedicated technical onsite technicians
- B. factory configuration
- C. onsite deployment of products
- D. legal advice for software problems
- E. a pay-per-use model for calls
- F. additional support and levels of availability

Correct Answer: BCF

QUESTION 4



After replacing a defective memory module, you boot the latest version of SmartStart so you can run a custom diagnostic test to ensure that previous problems have been resolved. After loading HP Insight Diagnostics, which tab should you choose to set up a user-defined memory test?

- A. Complete Test
- B. Diagnose
- C. Quick Test
- D. Custom Test

Correct Answer: D

QUESTION 5

You replaced a defective memory module in a ProLiant Blade server. On Boot up, you noticed errors during POST, but the screen cleared before you could see what happened.

Where can you view these errors now that the server has booted up to Windows?

- A. Windows Event Viewer Application log
- B. HP Insight Diagnostic POST tab
- C. Integrated Management log
- D. HP Insight Diagnostics Diagnose tab

Correct Answer: C

[HP2-T26 VCE Dumps](#)

[HP2-T26 Practice Test](#)

[HP2-T26 Exam Questions](#)