



HP2-T26^{Q&As}

Servicing HP BladeSystem Solutions

Pass HP HP2-T26 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.passapply.com/hp2-t26.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by HP Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers





QUESTION 1

A customer purchased a c7000 blade enclosure, fully populated with blade Gen8 servers and Care Pack services. Several days later, the customer purchased an HPZR30W, an HP UPS R8000/3, and two iPDUs.

Which new items will be covered in the Care Pack services? (Select two.)

- A. both iPDUs if they are mounted in a different rack from the c7000
- B. the ZR30W (30 inch) monitor put on top of a rack.
- C. both iPDUs if they are mounted in the same rack as the c7000
- D. the UPS R8000/3 if it is mounted in another rack
- E. the UPS R8000/3 if it is in the same rack as the c7000

Correct Answer: AC

QUESTION 2

What is the correct UEFI shell command to display a list of drivers on an HP Integrity BL860c i2 Server Blade?

- A. drivers
- B. map
- C. drvdiag
- D. drvcfg

Correct Answer: A

QUESTION 3

Which new technologies are introduced in the new G7 Series c-Class server blades? (Select two)

- A. Fully Buffered DIMMs
- B. Flex-10 Ethernet support
- C. 10Gb Ethernet on-board
- D. FlexFabric support
- E. Internal MicroSD card slot

Correct Answer: CD



QUESTION 4

How does a c7000 enclosure retain air handling integrity when a fan is removed?

- A. The enclosure design uses blank panels to prevent air loss.
- B. A blanking panel causes the air flow to reverse, allowing warmer air to escape.
- C. The enclosure uses a self-closing door to prevent air loss.
- D. The fans increase in revolutions per minute to increase air volume.

Correct Answer: C

QUESTION 5

You are installing a new HP BladeSystem c7000 enclosure. The customer wants to configure the iLO and interconnect IPs so that they are automatically maintained during a hardware swap.

How should you configure the enclosure?

- A. Use the Insight Display fixed IP feature.
- B. Use Enclosure-Based IP Addressing.
- C. Use Insight Control Server Deployment to configure the enclosure.
- D. Configure the IP on each device and enable enclosure IP mode.

Correct Answer: B

[HP2-T26 PDF Dumps](#)

[HP2-T26 Practice Test](#)

[HP2-T26 Exam Questions](#)