

H13-621^{Q&As}

HCNP-Storage-CUSN(Constructing Unifying Storage Network)

Pass Huawei H13-621 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

https://www.passapply.com/h13-621.html

100% Passing Guarantee 100% Money Back Assurance

Following Questions and Answers are all new published by Huawei Official Exam Center

Instant Download After Purchase

100% Money Back Guarantee

- 😳 365 Days Free Update
- 800,000+ Satisfied Customers





QUESTION 1

Main technical or functional of S5000T storage systems to enhance the reliability of the data are cache may fall protection, disk copy, global hot standby disk.

A. True

B. False

Correct Answer: A

QUESTION 2

What is the command to check WWN number of FC-HBA card in AIX system?

A. Iscfg-pvl fcsO

B. hba

- C. Isdev -Cc adapter Igrep fcs
- D. hbainfo

Correct Answer: A

QUESTION 3

Under Linux, which are the basic principles of the dd command test performance tuning? (Select 3 Answers)

A. read and write by bytes, collect performance data in an all-round way

B. it suggest that setting up reading and writing block is from big to small

C. in the process of reading and writing and performance testing, for IO influence factors, need to analysis, and find out the reason

D. analysis from small to large, and analysis of the online business is more efficient at the same time

Correct Answer: ABC

QUESTION 4

During the following several kinds of optical fiber network topology, which topology network can extend equipment (nodes) up to?

- A. switching topology
- B. Point to point



- C. the arbitration ring
- D. hybrid networking

Correct Answer: A

QUESTION 5

Which of the following scenarios can preliminary positioning storage array controller is abnormal or fault? (Select 2 Answers)

A. after the storage array is powered on, the fault indicator light of the front panel flashes orange

B. in the case of serial port cable and serial port parameters without exception, no printed information in the controller serial

C. controller state indicator light is red; it has inability to access the storage system

D. storage is powered on, front panel system failure indicator light red show that the controller must be failure

Correct Answer: BC

H13-621 VCE Dumps

H13-621 Practice Test

H13-621 Exam Questions