



NS0-184^{Q&As}

NetApp Certified Storage Installation Engineer, ONTAP

Pass NetApp NS0-184 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.passapply.com/ns0-184.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by NetApp
Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers





QUESTION 1

Click the Exhibit button.

```
Welcome to node setup.
```

```
You can enter the following commands at any time:  
"help" or "?" - if you want to have a question clarified,  
"back" - if you want to change previously answered questions, and  
"exit" or "quit" - if you want to quit the setup wizard.  
Any changes you made before quitting will be saved.
```

```
To accept a default or omit a question, do not enter a value.
```

```
Enter the node management interface port [e0c]:
```

You want to add a FAS2750 HA pair to an existing 6-node cluster.

Referring to the exhibit, which action would you perform to begin adding the node?

- A. Use the back command to begin the Cluster Setup wizard.
- B. Reboot the node and enter maintenance mode and run the Cluster Setup wizard.
- C. Use the node setup wizard and select 0a as the management interface.
- D. Use the exit or quit commands then run the cluster setup command.

Correct Answer: C

Reference: [http://docs.netapp.com/ontap-9/topic/com.netapp.doc.dot-cm-sag/System% 20administration.pdf](http://docs.netapp.com/ontap-9/topic/com.netapp.doc.dot-cm-sag/System%20administration.pdf) (35)

QUESTION 2

Click the Exhibit button.

```
Mar 18, 2020 07:35:35 CDT HA Group Notification (CLUSTER NETWORK DEGRADED) ALERT  
  
Mar 19, 2020 22:04:20 CDT HA Group Notification (Health Monitor process cshm:  
SwitchIfInErrorsWarn_Alert[NODE_NAME-sw1(SWITCH_SERIAL_NUMBER)/Ethernet1/8]) ALERT  
  
Mar 12, 2020 20:58:38 CDT HA Group Notification (Health Monitor process cshm:  
SwitchIfInErrorsWarn_Alert[NODE_NAME-sw1(SWITCH_SERIAL_NUMBER)/Ethernet1/8]) ALERT
```

Your ONTAP cluster shows the cluster network errors that are shown in the event log. What is used by ONTAP software to log the errors that are shown in the exhibit?

- A. SNMP
- B. AutoSupport



- C. BGP
- D. EMS

Correct Answer: D

QUESTION 3

You are installing a 4-node AFF A400 cluster and are asked to create a custom security message before and after user login.

Which two security features are used to perform this task? (Choose two.)

- A. EMS
- B. banner
- C. motd
- D. AutoSupport

Correct Answer: BD

QUESTION 4

While testing a recently installed FAS8700 cluster, a node fails. You now need to replace the impaired node.

In this scenario, which two statements are true? (Choose two.)

- A. You must move the boot device from the impaired node to the replacement node.
- B. The boot device must remain intact and must not be removed from the impaired node.
- C. You can change any drives or disk shelves as part of this replacement procedure.
- D. A controller model of the same type must be used to replace the impaired node.

Correct Answer: AD

Reference: https://library.netapp.com/ecm/ecm_download_file/ECMP1147156 (2)

QUESTION 5

Click the Exhibit button.





You plan to install a new ONTAP cluster at a customer site by using the new ONTAP System Manager 9.7 GUI.

Referring to the exhibit, what must you do before you provision initial storage?

- A. Configure cluster LIFs.
- B. Configure protocols.
- C. Configure a remote tier.
- D. Configure aggregates.

Correct Answer: D

[NS0-184 VCE Dumps](#)

[NS0-184 Study Guide](#)

[NS0-184 Exam Questions](#)