



NS0-182^{Q&As}

NetApp Certified Storage Installation Engineer, ONTAP

Pass NetApp NS0-182 Exam with 100% Guarantee

Free Download Real Questions & Answers **PDF** and **VCE** file from:

<https://www.passapply.com/ns0-182.html>

100% Passing Guarantee
100% Money Back Assurance

Following Questions and Answers are all new published by NetApp
Official Exam Center

-  **Instant Download** After Purchase
-  **100% Money Back** Guarantee
-  **365 Days** Free Update
-  **800,000+** Satisfied Customers





QUESTION 1

You have just installed a new AFF A220 4-node cluster with ONTAP 9.5 for a customer. Which two cluster switches are supported in this scenario? (Choose two.)

- A. Cisco Nexus 5596UP
- B. Brocade 6510
- C. Cisco MDS 91485
- D. NetApp CN1610

Correct Answer: AD

QUESTION 2

```
cluster::> system node autosupport history show -node node1
```

Node	Seq Num	Destination	Status	Attempt Count
node1	1	smtp	re-queued	13
		http	ignored	15
		https	failed	15

You configured AutoSupport and are trying to send a full AutoSupport message to NetApp. You use the autosupport history show command and see the output shown in the exhibit. The customer confirms that the AutoSupport settings are correct.

Which two actions will solve this issue? (Choose two.)

- A. The customer needs to enable AutoSupport for both nodes.
- B. The customer needs to exclude the two nodes from the attachment-size limitation.
- C. The customer needs to change the transport protocol to HTTP.
- D. The customer needs to white-list the two nodes on their mail server.

Correct Answer: AC

QUESTION 3



Which LIF type is used by default for hardware-assisted storage failover communication?

- A. intercluster
- B. node-mgmt
- C. data
- D. cluster-mgmt

Correct Answer: B

Reference: https://docs.netapp.com/ontap-9/index.jsp?topic=%2Fcom.netapp.doc.dot-cm-cmpr-950%2Fstorage__failover__hwassist__show.html

QUESTION 4

A customer wants to reduce the disk allocation requirement for the root aggregate and increase usable storage by partitioning the disks into one large part and one small part. The small part is used for the root aggregate and the large part for the data aggregates.

In this situation, what is this feature called?

- A. ONTAP
- B. storage virtual machine
- C. Advanced Drive Partitioning
- D. RAID

Correct Answer: C

QUESTION 5

You finished an ONTAP 9.5 installation using the information provided by the customer, but the NFS exports and CIFS shares cannot be accessed using the newly created data LIFs.

In this situation, which action should you perform before you leave the customer's site?

- A. Advise the customer to buy Cisco switches because NetApp supports only Cisco switches for CIFS and NFS.
- B. Review the ONTAP network configuration with the customer and make sure that it is correct.
- C. Connect to the customer's switch infrastructure and reset the port configurations.
- D. Advise the customer to solve the issue on their own, this is not part of a basic installation.

Correct Answer: B